



ATV FERTILISER SPREADER

MANUAL MODEL

Our ATV Fertiliser Spreader is perfectly suited for All Terrain Vehicles (ATV's) and more suited to Rough Terrain Vehicles (RTV's) as it can be controlled without leaving the driver's seat. This makes it easier and safer to use as the operator does not have to leave the seat. With its heavy-duty galvanized frame and polyethylene hopper, the ATVFS500M is built to last and endure the harsh environment that fertiliser spreading can bring. Its low fill height and wide wheelbase ensures the ATV Fertiliser Spreader is suited for all types of terrain and is incredibly stable.

Features

- Heavy Duty Galvanised Frame.
- Large Capacity Polyethylene Hopper (500L).
- Stainless Steel Nuts and Bolts.
- Swivel Ball Hitch.
- Extreme grip off road 4 Ply Tyres always ensures optimum traction.
- Manual Control of both Gearbox Engagement and Rate of spread.
- Cover for Fertiliser Hopper for Rainy Days.
- Mudguards to prevent the transfer of muck or clay into hopper.
- Adjustable Drawbar and Spreader veins ensure even spreading.

Safety

- Only experienced personnel should operate this ATV Fertiliser spreader.
- If you are unsure, please seek guidance.
- Caution should be taken when working on steep hills, taking into consideration the towing capacity of your ATV or towing vehicle.
- Caution should be taken when working with fertiliser as it may cause serious eye irritation.



Pre-Towing Checks

Before operating the ATV Fertiliser Spreader, the following recommended pre-towing checks should be completed by the operator:

- Ensure the hitch is securely fitted onto the drawbar and has no defects.
- Ensure the control cables are unimpaired and above the floor.
- Ensure the chocks are removed from the wheels.
- Ensure the tyres are sufficiently inflated with no visible damage.

Features

- Drive with caution at slow speeds ensuring not to exceed max towing speed of 25km/hr.
- Do not exceed the towing capacity of your ATV/RTV.
- Avoid sudden steering or braking manoeuvres, especially when the ATV Fertiliser Spreader is filled.
- The ATV Fertiliser Spreader is not suitable for highway use.
- Passengers are not permitted to ride on or in the ATV Fertiliser Spreader.
- Do not modify or alter the ATV Fertiliser Spreader in any way, doing so may expose operators to hazards. If assistance is required, please contact us directly.
- When not in use, park the ATV Fertiliser Spreader on a smooth level surface and apply wheel chocks to both wheels.

Storage

- Fertiliser is very corrosive, so it is vital to follow these instructions to ensure long working life of the ATV Fertiliser Spreader:
- Clean spreader after use.
- Lubricate all moving parts.
- Apply anti corrosive protection.
- Store spreader safely.
- Replace any damaged parts.

Spreader Settings and Coverage

Setting	Kg/Acre	Bags/Acre
1	1	-
2	2	-
3	3	0.1
4	11	0.2
5	25	0.5
6	50	1
7	75	1.5
8	100	2
9	125	2.5
10	150	3

